

Začiatok:

- Pripojte napájací adaptér do zásuvky.
- Pripojte napájací zdroj k CCE 20. Ak sa zariadenie nezapne automaticky, stlačte a podržte ON/OFF na 2 sekundy.
- Do zariadenia môžete začať vkladať bankovky pre otestovanie (vkladajte po jednej).
- Vložené bankovky budú otestované a v závislosti od nastavenia zariadenia sa vysúvajú späť bud prednou stranou alebo zadnou stranou zariadenia
- Podozrivé bankovky sa spravidla vysunú vstupnou stranou a naznie výstražný tón, ktorý Vás informuje že bankovka nebola akceptovaná.

Čistenie senzorov

Bankovky a usadený prach spôsobujú usadeniny v oblasti senzorov zariadenia. Tieto nečistoty vedú k zvýšenému počtu nezistení pravých bankoviek. Preto je potrebné pravidelne čistiť sensory CCE 20. Pri čistení zariadenie vypnite a odpojte od napájania. Uchopte rukoväť na boku zariadenia (obr. Č.4) a otvorte hornú časť prístroja smerom hore a do strany. Usadeniny zo senzorov a pásov na posun bankoviek môžete odstrániť pomocou mäkkej kefy a handričky na čistenie okuliarov. Prípadne si môžete objednať špeciálne čistiaci karty a sprej na stlačený vzduch na profesionálne čistenie.

Zmena meny a aktualizácie

Zaregistrujte sa na našej stránke www.cce.gmbh, aby ste dostali náš bulletin. Spravidla sa odosielá 8 krát ročne a informuje vás o potrebných aktualizáciách (napr. Pri nových bankovkách). Všetky informácie o dostupných aktualizáciách alebo kombináciach mien nájdete na našej webovej stránke.

Kontakt

V prípade akýchkolvek problémov s vašim CCE 20, ktoré nie je možné vyriešiť pomocou tohto manuálu, sa obráťte najskôr na svojho predajcu. Uschovajte si svoju faktúru o nákupu ako doklad o záruke. Štítok s výrobňím číslom nesmie byť odstránený ani poškodený alebo zmenený iným spôsobom inak zariadenie stratí záruku. Ak chcete vrátiť zariadenie na opravu alebo servis je potrebné zariadenie poslať spolu s kópiou faktúry a reklamačný popisom o prejavenej závade.



CCE 20 - Tester bankoviek

Pohľad spredu	Pohľad zozadu
SLOVENSKY	ANGLICKY
<p>1. Zvolený smer výstupu vložených bankoviek 2. Zobrazenie aktívnej meny 3. Zobrazenie hodnoty bankovky / súčet testovaných bankoviek v závislosti od nastavenia 4. Zobrazenie počtu testovaných bankoviek 5. Zobrazenie stavu batérie (batéria voliteľná) 6. Zobrazenie zvoleného smeru výstupu bankoviek 7. Zobrazenie zvoleného režimu (ADD = súčet DEN = zobrazenie jednej hodnoty) 8. Úchytka na otvorenie zariadenia 9. LED lišta na indikáciu stavu 10. ▲▼ tlačidlo : Podržaním zmeníte smer výstupu prijatých bankoviek 11. ON/OFF - tlačidlo: Stlačením a podržaním prístroj zapnete alebo vypnete. Po zapnutí môžete vypnúť alebo zapnúť signálny tón rýchlym stlačením tlačidla 3x. 12. MODE tlačidlo: Krátkym podržaním zmeníte režim zobrazenia (pridanie, alebo jedna hodnota). Podržte tlačidlo dlhšie aby ste vymazali zobrazenie na displeji. 13. Výstup bankoviek, všeobecný smer výstupu podozrivých bankoviek, zvolený smer výstupu prijatých bankoviek. 14. Kryt batérie pre voliteľnú batériu 15. Štítok s výrobňom číslom 16. Mini-USB-Port pre servis 17. Napájací zdroj 12 V DC 1 A 18. Zvolený smer výstupu bankoviek 19. Micro-SD na výmenu menu alebo aktualizáciu FW.</p>	<p>1. Selected reverse output direction of accepted banknotes 2. Display of the active currency 3. Display of the banknote value / sum of tested banknotes depending on selected mode 4. Display of the number of tested banknotes 5. Display of battery status (battery optional) 6. Display of the selected output direction of accepted banknotes 7. Display of the selected mode (ADD = addition of the accepted notes, DEN = single value display) 8. Grip for opening the device 9. LED bar to indicate operational status 10. ▲▼ Key: Hold down to change the output direction of accepted banknotes. 11. ON/OFF key: Press and hold to switch the device on and off. When switched on, press 3 times quickly in succession to switch the signal tone on or off. 12. Mode Key: Hold down shortly to change the display mode (addition or single value) Hold down longer to clear the display 13. Banknote withdrawal, general output direction of suspected banknotes, selected output direction of accepted banknotes 14. Battery cover for optional rechargeable battery 15. Type plate with serial number 16. Mini USB port for service technicians 17. Power supply unit Port 12 V DC 1 A 18. Selected reverse output direction of accepted banknotes 19. Micro SD slot for optional SD card for currency exchange and currency updates</p>

Start-up:

- Connect the power supply unit to the socket.
- Now connect the power supply to the CCE 20. If the unit does not switch on automatically, press and hold the ON/OFF button for 2 seconds.
- Now insert the banknotes to be tested one by one into the device.
- The banknotes are drawn in and checked, accepted banknotes are ejected back to the input side or back to the front depending on the setting.
- Suspect notes are generally ejected to the input side and a warning tone is emitted to inform you that this note has not been accepted.

Cleaning the sensors

The banknotes and the settling dust cause deposits in front of the machine's sensors. These impurities lead to an increased number of non-detections of genuine banknotes. Therefore, please clean the sensors of the CCE 20 at regular intervals. When cleaning the machine, generally switch off the device and unplug the mains plug. Grab the grip on the side of the device (Fig. No. 4) and open the upper part of the device upwards and to the side. You can remove the deposits from the sensors and from the banknote conveyor belts with a soft brush and a glasses cleaning cloth. Alternatively, you can order special cleaning cards and compressed air spray for professional cleaning from our web shop (www.cce.gmbh).

Currency change and updates

Registre free of charge on our website www.cce.gmbh for our newsletter. As a rule, it is sent out 8 times a year and keeps you up to date and necessary updates. All informations on available update or other currency combinations can also be found on the website in the Software section

Contact Us

In case of any problems with your CCE 20 and you cannot solve these problems with the help of the manual, please contact your dealer first and our service team by email at info@cce.gmbh if you have any further questions.

Please keep your sales invoice as proof of warranty. The type label on the back or underside of the machine with the serial number must not be removed, pasted over, damaged or altered in any other way, otherwise the warranty may be void. If you wish to return equipment for repair or service, please generally use the RMA counterfeit detector form on the website www.cce.gmbh in the Service section. There you will also find all the necessary information for returns processing.